EMP4 Inductive Mp3 Player Box

2014,Upgraded Design!

Thank you for purchase, Inductive Mp3 player box.
Please read this user manual carefully before any operation.

Mechanical Diagram



<Front View>



<Right/Left View>

Features

1)Playing files in TF card and Record Files
2)Recording Function
3) Remote Control
4) 3.5W Power Amplifier
5) AUX-IN Input, auto-shift after plug in
6) Soft Power ON/OFF button
7)LED Charging Direction
8) Charing and Battery Volume Alarm, Led in Red When charing

Guick Start Guidance

1) POWER: press for 2~3 seconds to turn on SE23, indicate LED flashes three time after turn on, press 1 second to pause in playing. Press 2~3 second to turn EMP4 off,indicator will keep green for 2 seconds and then off.

2) MUTE: default status with Audio Output function after turn on. Press "MUTE" for one time to stop audio output function, press again "MUTE" again, audio output function works again. Indicator LED lasts for two second and off in status of "MUTE". When playing music, indicator flashes every two seconds. Switch again to restore the audio output to the state.

3) REC : After boot any state, long press the "REC" button to enter the recording standby state, long bright light, and then a short press to enter the recording mode,the recording is automatically saved, LED flashes during recording, the recording process, press the "REC" button to pause recording , LED long lights, press "REC" short period to next recording, long pressing the "REC" button to exit the recording.

4) Recording Playback: boot any mode, press "REC" to enter the recording standby state, press "POWER" button to pause playback audio file, press the switch on the "Previous" or "Next" to play the former or next content. Indicator status same as MP3 playback

5) Delete: Connect to PC and delete recording files

Package Includes

1 x Inductive Mp3 player box
1 x USB AC Power adaptor
1 x USB cable
1 x Remote Control

*White color only

<1>Recharge

The Red light will turn on while recharge
Full recharge takes about 2 hours. After
full recharged, the red light will turn off.

* You can recharge the battery while playing music.

<2>Load TF Card

Please use regular TF card (size 10x14mm)
Make sure this pins adown

<3>Turn on /off

Press “Power” button and hold for 3 seconds, Blue light will flash 3 times when turn on.
In power on status, press “Power” button and hold for 3 seconds will turn off the power.
In power on status, short press to pause / play.

<4>MUTE

In order to avoid been detected.
you can push MUTE button to cut off audio output.
After pushed Mute button, the music will stop.
Push the MUTE button again will reactive audio output.

* Mute button is invalid in power off status.

<4>REC

Long press to enter recording status.
Then short press to start recording.
The recording is automatically saved.
Then short press to stop recording.
Long press to exit the recording.

Thank you for reading and Happy Ecommerce!